

Grinding Between Weld Passes

No. Section J2 of the AISC *Specification* states that, with a few exceptions, all provisions of AWS D1.1 apply under the *Specification*. Section 5.15 of AWS D1.1 requires that the surface to be welded shall be free of slag or other items that would be detrimental to the welds. It does not require grinding between passes.

Carlo Lini

Reuse of Fasteners Not Addressed in RCSC *Specification*

The RCSC *Specification* does not address the use of A354 Grade BD fasteners, and ASTM A354 does not address reuse. Therefore, there is no explicit prohibition against reusing A354 Grade BD bolts. Since it is not addressed, you will have to use your own judgment.

The Commentary to the RCSC Specification states: "Pretensioned installation involves the inelastic elongation of the portion of the threaded length between the nut and the thread run-out. ASTM A490 bolts and galvanized ASTM A325 bolts possess sufficient ductility to undergo one pretensioned installation, but are not consistently ductile enough to undergo a second pre-tensioned installation. Black ASTM A325 bolts, however, possess sufficient ductility to undergo more than one pre-tensioned installation as suggested in the Guide (Kulak et al., 1987). As a simple rule of thumb, a black ASTM A325 bolt is suitable for reuse if the nut can be run up the threads by hand."

The point of the foregoing is that A490 bolts have less ductility than the A325 bolts because they are of higher strength. Section J3.1 of the AISC *Specification* indicates that in order to ensure proper pre-tension the A354 Grade BD would have to have "bolt geometry including the thread pitch, thread length, head and nut(s)... equal to or (if larger in diameter) proportional to that required by the RCSC *Specification*." In other words, the A354 grade BD fastener you are proposing in place of the A490 bolt will be nearly identical to an A490 bolt. Therefore, it seems likely that the same reuse prohibition would be applicable.

Note also that your repeated pre-tensioning and loosening means A325 bolts likely would not be suitable for your intended use either. The *Guide to Design Criteria for Bolted and Riveted Joints* (a free download from states: "A325 bolts can be reused once or twice, providing that proper control on the number of reuses can be established."

Carlo Lini

Economical Weld Details

The AISC *Specification* never requires the use of CJP groove welds. There are some instances in the AISC *Seismic Provisions* when CJP groove welds must be used. CJP groove welds often are specified because it is easy to write and there are no calculations associated with them—not the most economical of reasons in the shop and field, of course.

You are correct that a fillet weld is often the more economical choice. However, when a fillet weld becomes very large, a CJP groove weld can become the more economical choice. The advantages of the options available must be weighed. The cost of providing the prepped edge (for the CJP) must be weighed against additional weld volume and passes (for the fillet). There may also be additional inspection requirements for a CJP groove weld to consider as well. There are also other options such as a PJP groove weld, with or without reinforcing fillets.

Note also that a fillet weld may or may not require less weld metal than a CJP weld.

Let's compare a 1-in. plate welded with a ¾-in. fillet weld on both sides to the same plate with a CJP groove weld. The theoretical volume of the fillets is one-half the base times the height, or $2(0.5)(0.75)^2 = 0.563$ in.²/in. for both welds. The volume of the CJP groove weld depends on the configuration. If we assume a B-U4a with a 45° bevel, the volume will be $0.5(1)^2 + 0.25 = 0.75$ in.²/in. However, you may still have fewer passes and therefore less labor and less cost. Some configurations will actually result in less weld volume and fewer passes.

If you look at Table 8-12 in the *Manual*, you will see that a ¾-in. fillet requires about 8 passes (16 passes for both welds). A CJP groove weld with a 45° single bevel requires 11 passes. This can actually drop to as few as five passes when a 30° double bevel is used and the volume of weld metal is decreased. Of course, there will be some additional cost associated with providing two bevels instead of one. It should also be noted that the table provides only approximate values but even these approximate values can help evaluate alternatives.

There are a lot of variables to consider. What is the cost of beveling the edge versus the cost of the additional passes? Will the CJP groove weld have to be evaluated with ultrasonic inspection (UT), adding an additional step to the process? Will the member have to be flipped to complete the double bevel and the welding? Can the flipping be accomplished with a single crane or will it tie up multiple cranes and operators? Unless you know the answers to these questions it will be difficult, if not impossible, to choose the optimal weld. That is why it is often best to allow the fabricator to choose the best option.

Larry S. Muir, P.E. addition.t@nultile cran

90

A G 2015